Power Bank

User's Manual

- · Meeting your emergency and mobile charging needs.
- · Suitable for nearly all kinds of mobile phones and digital products with USB connector.
- Built-in protection ICs to avoid over-charge, over-discharge, over-current and short circuit.
- Intelligent power management solution for steadiness and high efficiency.


Operation Instructions:


• Connect your device to the output of the Powerbank with a compatible cable (USB Type-A for the Powerbank connection) (see picture below).



- . To charge the Powerbank
- Method I: Connect the Input of your Powerbank with a Power Adapter (5V/2A max.). (see picture 1)
- Method II: Connect the Input of your Powerbank with a Computer. (see picture 2)

Depending on the model of the Powerbank, you can charge by micro-USB connection and/or a Lightning connection





FAQ

- Q: Unable to charge Powerbank.
- A1: Check if power adapter is the right one and if the connecting cable and connector work well.
- Q: Powerbank unable to charge your device.
- A1: Powerbank voltage is too low, please charge it first.
- A2: Your device voltage is not compatible with Powerbank output voltage, please check your device voltage.
- A3: Wrong connection between your device and the Powerbank, or unqualified connecting cable and connector. Please check them and use qualified ones.
- A4: Powerbank failure, please contact your local distributor.

TIPS

- Please charge Powerbank once at least every 3 months if not used for a long time.
- When used, Powerbank gets a bit hot. It is normal if the temperature is not over 60 degrees Celsius.
- Keep Powerbank dry, do not wipe with chemical cleansers.
- Take care of the environment, please recycle Powerbank at a designated place, do not dispose it randomly.

IMPORTANT

- Keep children and unqualified users out of reach of Powerbank, unless they are accompanied and quided by qualified people.
- Do not crush, self-dismantle, stab, wet, dampen and squeeze Powerbank.
- Do not place Powerbank in high temperature conditions, which may lead to its failure or cause fire.
- Do not charge a device that is not compatible with the Powerbank, otherwise it might cause failure or fire.